

# syngo BLADE

1. Finding the *syngo* BLADE sequences in the Exam Explorer. All *syngo* BLADE sequences are located in the BLADE folder of each body region library.
2. *syngo* BLADE trajectory, located on the common Resolution subtask-card.
3. BLADE Coverage parameter, located on the common Resolution subtask-card.
4. Use of Motion Correction, located on the Sequence subtask-card, part 2. A turbofactor of at least 29 must be used to activate this option.

